

Lubrication systems for injection pistons

MicroLub 2S



Lubrication by **MicroLub 2S**



Classic lubrication



The optimal solutions to lubricate injection pistons



Content

1. Introduction.....	2.
2. Presentation.....	3.
3. Installation	
3.1 Electric connections.....	4.
3.2 Pneumatic connections and nominal pressure adjustment.....	5.
3.3 Installation and filling up the system with lubricant.....	6.
3.4 Dose adjustment for an injection cycle.....	7.
4. Technical specifications.....	8.
5. Maintenance operations.....	9.
6. Components.....	10.
7. Troubleshooting.....	11.
8. Contact VGA Die Cast Solutions.....Facebook, YouTube, website/Contact....	12.

1. Introduction Top

General information

The equipment intended to dispense lubricating oils made be Chem Trend (with combustion point higher than 150 ° C).

Any other or expended use of the equipment is considered to be a non-designated use, and is there fore not authorized. These cases can result in safety impairments. VGA Die Cast Solutions assume no liability and kind for any losses resulting from non-designated uses.

This manual contains information regarding the use, maintenance of the microdosing system MicroLub 2s, which is an integrated part of this product.

The instructions contained in this manual represent the general conditions of operating the microdosing system MicroLub 2s, for which VGA Die Cast Solutions reserves its rights to bring modifications in the purpose of further improvement of quality.

THE DEALER WILL BE RELIEVED OF ANY RESPONSIBILITY IN THE FOLLOWING CASES:- bad operation of the machine; - operation which is against the specific legislation; - incorrect installation; - power supply defects; - serious maintenance faults

- modifications and interventions which are not authorised or supervised by the producer; - using spare parts which are non-original or unauthorised by the machine supplier – full or partial violation of instructions; - in exceptional situations.

GENERAL INFORMATION REGARDING THE SAFE USE OF THE MicroLub 2s doser.

Read carefully the manual and do not start the installation when you notice malfunctions.

The producer reserves its right to improve the products without bearing the obligation to inform the users about the equipment supplied previously.



For assistance regarding the exploitation of **MicroLub 2s**, during or after the warranty period, please contact us by email at service@vgadiecastsolutions.com.

Thank you!

2. Presentation



General features

MicroLub 2s has been designed and built to operate with dry and degassed compressed air, according to ISO 8573-1.

The volumetric pump has been designed for different lubricants. The maximum admitted viscosity is 100.000 cSt.


The lubricants or the used liquids must not be aggressive towards the materials which the pump is made of (aluminium and NBR) and must not generate toxic steam which may harm people's health or may be a fire hazard.

If substances which do not follow these requirements are used, one must adopt the adequate solutions, depending on every particular case, with the approval of the producer.

The machine must be operated by the staff which had been previously trained in the features of the machine and is well aware of the contents of this manual.

3. Installation Top

3.1 The electric connexions of the MicroLub 2s doser



3.2 Pneumatic connections and regulator pressure adjustment Top


By turning the regulator pressure button you will get the nominal work pressure of the volumetric pump, which has to be between 3.5 and 5 bars, value displayed on the installed manometer's gauge.



The microdoser Microlub 2s connects to the compressed air installation by a ¼ hose fitting, the necessary pressure at the box inlet is between 5 and 8 bars.

”

3.3 The installation and fill-up of the lubricant system Top



3.4 Lubricant dose adjustment



The clack for the manual actuation of the electrovalve. For starting the electrovalve one can use the clack if the electric signal for actuation cannot be generated manually

The screw for adjusting the lubricant dose per cycle. By turning the adjustment screw, each gradation



4. TECHNICAL SPECIFICATIONS



Range of doser adjustment	Min 0,2 cc Max 2 cc	1 gradation = 0,2 gram
Tank capacity	10 Lt	
Size		
Height	355 mm	
Width	330 mm	
Depth	225 mm	
Unladen weight	10 kg	
Supply voltage	24 Vcc	contact 2 and ground wire contact 1
Maximum current draw	0,35 A	
Air pressure necessary at box inlet	Min 5 bar; Max 8 bar	
Work pressure of the volumetric pump	3,5 – 5 bari	
Command to turn off machine when tank is empty	Yes	
Output signal values for turning off the machine	+24 V Stop machine, 0V machine is on	contact 4 and ground wire contact 1
Optical Indicator for pump ON	Yes	intense green light
Optical indicator for no lubricant	Yes	
Indicator for level of lubricant in the tank	Yes	tube rilsan
Optical indicator for activation of the signal STOP machine	Yes	red light
Indicator supply voltage 24 Vcc	Yes	normal green light
Air pressure regulator for pump inlet	Yes	
Volumetric doser with linear adjustment of quantity	Yes	
Anti-corrosive protection for the tank	Yes	stainless steel


5. Maintenance work Top

We recommend the following actions so that the MicroLub 2s system runs smoothly:

- Periodic check and removal (if necessary) of lumps or particulate matter from the lubricant tank.
- The lubricant level in the tank is to be checked by observing the indicator on one side. If needed, add some lubricating agent.
- Check/Adjust the pressure indicated by the built-in manometer, which has to be between 3.5 and maximum 5 bars.
- The dosage is to be checked and if needed proceed to adjusting the quantity of lubricant by adjusting the volumetric pump.
- Check the control green light, which indicates the machine power supply with 24V. If no such voltage, then the stop signal cannot be transmitted in case the lubricant level in the tank is under the safety limit.
- Check the receipt of the “start lubricating” signal, which is signalled by increasing the intensity of the green light, on the front panel.
- Check if the Rilsan tubing is connected/sealed correctly inside the MicroLub 2s.

In certain cases. the turning off functionality of the system can be tested. For this. you empty the lubricating agent tank, to the minimum, which will switch on the red light on the front panel and transmit the signal to turn off the die casting machine.

6. Components Top



01. Manometer
02. 1/4" Hose
03. Pressure regulator.
04. 1/8" Hose
05. Minimum level detector
06. Volumetric pump
07. Connector solenoid valve coil
08. Solenoid valve
09. Solenoid valve's coil
10. Screw for tank fixing
11. Impurities filter
12. O-ring for sealing
13. 1/4, 1/8 grease fitting (grease nipple)
14. O-ring for sealing
15. Gland hose
16. 1/4, 1/8 Grease fitting
17. 1/4 Hose
18. Hose
19. Screw to block the door
20. Turn off machine alarm. Insufficient lubricant level
21. Hose with protection for transmitting the lubricant doses
22. 1/4 Tube hose
23. Metal shaft
24. Nut for fixing the tank lid
25. Screw for fixing the tank lid
26. Green light for signalling presence of +24V
27. Indicator for lubricant level in the tank



7. Troubleshooting Top




The doser does not release lubricating agent through the metal shaft

- check the level of the lubricant in the machine
- check the lubricant supply tube
- check the metal shaft and reposition it if necessary

The doser does not send lubricant agent doses (the piston does not move)

- check the voltage and the length of the command impulse
- check the fuse from the distributor
- check the inlet air pressure



  	<p>CERTIFICATE OF CONFORMITY</p>	 <p>OUR CUSTOMERS</p>
<p>GIFA EUROGUSS 2021-2024</p>		<h2>MICROLUB 2S</h2>
<p>SC VGA Die Cast Solutions SRL</p>		<p>35 Fagului Street, 440186 Satu Mare, România</p>
<p>RO 36132916</p>		<p>Phone: (40) 0721.957.469 (40) 0744.959.839</p>
